



EXPLODED VIEW & PARTS LIST

MODEL 1077 RepeatAir[®] .177 cal. CO₂ Rifle



Manufacture Dates: 8/30/01 to Present

Last Update 1/7/13

CROSMAN CORPORATION
7629 ROUTES 5 & 20
BLOOMFIELD, NY 14469
Phone: 1-800-724-7486
Parts Order Fax: 585-657-5405

www.crosman.com

- This EVP and parts list is intended to be an informational guide in ordering parts. It is not instructional material and we therefore assume no responsibility for those who use the same without proper factory training.
- Please order by part number and description.
- Check or money order for the total price must accompany the order.
- For current prices contact Crosman Corporation at 1-800-724-7486 or visit our website www.crosman.com

PARTS LIST for 1077

Manufacture Dates: 8/30/01 to Present

PART NUMBER	DESCRIPTION		
1	10895	Receiver, Left Hand	1
2	1077-032	Screw, Housing	2
3	1077-056	Pin	1
4	1077-055	Spring	1
5	1077A044	Latch, Hammer	1
6	1077-040	Safety	1
7	1077B027	Valve Assembly	1
7a	10604	Ring, Retaining	1
7b	2-160	Puck Assembly	1
7c	130-034	O-Ring, Seal .504.364.070	1
7d	40A028	Valve Stem	1
7e	106-008	Spring	1
7f	1077-053	Washer	1
7g	106-005	O-Ring	1
7h	1077B015	Valve Body	1
8	1077-057	Spacer, Valve	1
9	130-032	O-Ring, Seal .254 .114 .070	1
10	1077-028	Bushing, Valve	1
11	1077A038	Retainer, Bushing	1
12	106A046	Spring, Detent	1
13	106B011	Detent	1
14	106A010	Detent Body	1
15	1077-007	Latch	1
16	1077-006	Barrel, .177Cal 20.387LG	1
17	766-107	Elevator, Sight Delrin	1
18	262A200	Sight, Rear	1
19	66-032	Screw, Barrel Guide	2
20	1077-010	Barrel Housing	1
21	66-201	Sight, Front	1
22	1077-030	Hammer	1
23	106-035	Spring	1
24	766-044	Pin, Dwl .125DIA .937	1
25	10835	Pin	1
26	1077-008	Barrel Band	1
27	1077-026	Screw	1
28	1077-039	Spacer	1
29	1077A016	Tube, Transfer	1
30	1077-029	Tube, Bushing	1
31	130-032	O-Ring, Seal .254 .114 .070	1

PART NUMBER	DESCRIPTION		
32	1077-036	Plug Assembly	1
32a	1077A018	Plug, Piercing Brass	1
32b	38-028	Filter Screen, Brass	1
32c	T4-041	Pin, Spcl .500 DIA .177	1
32d	38-128	Seal, End .515 .170 .140	1
32e	338-041	Guide Collar, Valve	1
33	1077-031	Pin, Tube	1
34	1077A017	Tube	1
35	1077A046	Piercing Knob	1
36	1077A020	Stock Assembly	1
36a	77A011	Screw, Receiver Long	1
36b	1077-054	Butt Plate	1
36c	1077A019	Stock	1
37	1077-041	Screw, Stock	2
38	1077-042	Screw, Band	1
39	1077-002	Magazine Assembly	1
39a	2-041	Screw, Frame Long	2
39b	1077-004	Clip, Left Hand	1
39c	766-091	Spring, Cmprsn .026 MUW .82	1
39d	106-014	Lever, Index	1
39e	106-016	Spring, Index	1
39f	1077-003	Bar, Transfer	1
39g	1077-045	Pin, Loader	1
39h	106-015	Pawl, Index	1
39i	1077-005	Clip, Right Hand	1
40	1077-001	Pellet Clip	1
41	2-041	Screw, Frame Long	3
42	10896	Receiver, Right Hand	1
43	1077-033	Assy, Trigger	1
44	1077-014	Spring, Trigger	1

-	1077-034	Valve-Tube Assembly	
7	1077B027	Valve Assembly	1
8	1077-057	Spacer	1
9	130-032	O-Ring, Seal .254 .114 .070	1
10	1077-028	Bushing	1
11	1077A038	Retainer, Bushing	1
12	106A046	Spring	1
13	106B011	Detent	1
14	106A010	Detent Body	1
29	1077A016	Tube, Transfer	1

MODEL 1077

